




LEITFADEN ZUR AUSWAHL VON TJEP-BEFESTIGUNGSELEMENTEN FÜR IHR AKKUWERKZEUG



TJEP CPX BETON- NÄGEL	TJEP TF-18 STIFT- NÄGEL	TJEP TF-16 BRADS	TJEP GR RILLEN- NÄGEL	TJEP GF RILLEN- NÄGEL	TJEP AB-15 BRADS	TJEP VF-16 BRADS	TJEP BE-90 KLAM- MERN	TJEP AP ANKER- NÄGEL	TJEP PC RILLEN- NÄGEL	TJEP CN RILLEN- NÄGEL	TJEP FH RILLEN- NÄGEL	TJEP RA KLAM- MERN
-----------------------------	-------------------------------	---------------------	-----------------------------	-----------------------------	---------------------	---------------------	-----------------------------	----------------------------	-----------------------------	-----------------------------	-----------------------------	--------------------------



DBN500ZJ



DBN600ZJ



DFN350Z



DPT353Z

DST221Z



FN001



GF600SE



GN420CLSE



GN900SE



DCN650



DCN660



DCN680



DCN681



DCN682



DCN692



DCN693



DCN695



DCN890

DPN90C



DDF5110500



DDF5120550



DC602



DC608



DC616KB



DC618KN



DC628KB



DCN690M2



DCN690N



DCN690P2



NR1890DBCL



NR1890DBRL



NT1865DBAL



NT1865DBSL



NT1850DBSL



N18DSL

NR90GC2



NT1865DA



NT50GS



NT65GS



M18 FFN



M18 FN18GS



M18 FN15GA



M18 FN16GA



M12 BST



M18 FNCs18GS



M18 FFN21



GNH 18V-64 M



GSK 18



GNB 18V-38



Leitfaden zur Auswahl von TJEP-Befestigungselementen.
Die Übersicht dient als Orientierungshilfe für Verbindungselemente.

● Befestigungsmittel können verwendet werden.